

STUDIO•M

SM867644

Please consult your electrician for hanging fixture and wiring.

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box.
3. Wire fixture to wires in outlet box. Green wire is for Ground.
4. Install fixture to bracket and tighten finials in the canopy to secure.
5. Fit lens onto Canopy then screw into the Screws with the Allen Wrench.

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

Lutron MACL-153M

Lutron DVL-153P

Lutron SCL-153P

Leviton IPL06-10Z

Leviton 6674-POW

Due to the inrush current, wattage should not exceed 150 watts of product for a 600 watt dimmer.

